110V IN-LINE SOCKET

SAFETY WARNING

Before use please read carefully and use in accordance with these safety wiring instructions.
Before commencing any electrical work ensure the supply is disconnected. If in doubt consult a qualified electrican.



1. Undo the socket back screws and remove back section.
2. Rotate cable clamp out of the way of the terminals.

3. Feed flex through the rear gland in the plug back.
4. Remove the flex sheave to the required lengths as shown in the diagram.



5. Terminate the correct wires in the correct terminal blocks as shown in diagram.

6. Remove the cable clamp screws. Clip the cable clamp back into position, and place the cable clamp around the outer sheave on the flex. Replace the screws and tighten until the flex is securely held.
7. Replace the back cover and tighten the cover screws.

IF IN DOUBT CONSULT A QUALIFIED ELECTRICIAN

Masterplug Helpline: 0845 194 7584
Visit our Website: www.masterplug.com